

BP LIFTS

By Barker Products 1310 Miller Road, Greenville, SC 29607 Phone:800-349-3149—Fax:864-297-1292



BPH2-27 SERIES LIFTS






Powered By A 27K Helical Actuator
With

Splined Shafts To Eliminate Arm Movement & Wear For

Extreme Heavy Duty High Lift Applications 45" To 57" Mounting Heights 50" To 74" Dump Heights Over 50 Degree Dump Angle To Empty Can Oui

Over 50 Degree Dump Angle To Empty Can Quickly Dumps Deep Into Hopper to Prevent Spillage Hardened Steel Bearings At All Pivot Points



			DO NOT SCALE DRAWING	H2-2739 L				
BARKER PRODUCTS 1310 MILLER ROAD GREENVILLE, SC	DRAWN BY:	R WYMAN 5/22/2020	UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES: FRACTIONAL ±1/32 ANGULAR: MACH ±1° BEND ±1°	DRAWING NO BU18639 EN		JN2		REV 00
29607	MATERIAL:	NOTED	TWO PLACE DECIMAL ±0.010 THREE PLACE DECIMAL ±0.005	SCALE: 1:8	WEIGHT:	257.640	SHEET	1 OF 1




BP LIFTS

By Barker Products
1310 Miller Road, Greenville, SC 29607
Phone:800-349-3149—Fax:707-371-4886
WWW.BPLIFTS.NET




Lift Unit Installation

- 1. Truck must be empty, clean and parked on a level surface before installation is started.
- 2. Remove all bumpers and running boards that will interfere with the location of the lift units. Relocate lower mounted tail lights as needed.
- 3. Measure and mark the centerline of the truck hopper. The centerline of the unit or units should be a minimum of 17" from the hopper centerline.
- 4. Hand valves should be mounted on the side of the hopper at the most convenient height for the operator and clear of the packer controls.
- 5. The top of the unit mounting plate should be tack welded in place at the height recommended on the envelope dimension sheet of the unit. CAUTION: SEE NOTE BELOW PICTURE
- 6. All dimensions should be approved by the customer before final welding.
- 7. If the mounting plate extends more than 2" above the hopper, a brace should be added.



Mounting heights and locations are recommendations only. It is the responsibility of the installer to insure that the customer is satisfied with the height. Barker Products recommends that after the units are tacked in place, try the units with the can or cans the customer uses. The customer should approve your mount before final welding.



29607

MATERIAL:

NOTED

TWO PLACE DECIMAL ±0.010
THREE PLACE DECIMAL ±0.005

WEIGHT: 258.602 # SHEET 1 OF 2 SCALE: 1:8

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	BWA18502	MAINFRAME SUB ASSY H2-27XX	1
2	BW18548	LEFT LIFT ARM	1
3	BWA18540	LIFT PLATE SUB ASSY	1
4	BW18629	GUIDE ARM	2
5	BWA07490	HOOK SUB ASSY	1
6	BW18520	HOOK LINK DRIVE SPACER	2
7	BW18669	HOOK LINK	2
8	BW18549	RIGHT LIFT ARM	1
9	BW18002	O-RING GREASE SEAL	2
10	XAD081312	1/2-13 X 1 1/2 SHCS	2
11	BW99108	1/2" SPHERICAL BEARING	4
12	XEA062412SS	FLAT WASHER 3/8 X 1 1/2 X 1/8	6
13	XAE061606	3/8-16 X 3/4 FLANGED HHCS	6
14	XEA082412SS	FLAT WASHER 1/2 X 1 1/2 X 1/8	4
15	XAA081316	1/2-13 X 2 HHCS	4
16	XDA081300	1/2-13 HEX NUT	4



5/26/2020 DATE: MATERIAL: NOTED

DRAWING UNLESS OTHERWISE SPECIFIED: PARTS DRAWING
DIMENSIONS ARE IN INCHES
TOLERANCES. TOLERANCES: FRACTIONAL±1/32 ANGULAR: MACH±1° BEND ±1° TWO PLACE DECIMAL ±0.010 THREE PLACE DECIMAL ±0.005


DO NOT SCALE

H2-2739 LIFT UNIT

DRAWING NO BU18639 PARTS REV 00

WEIGHT: 258.602 # SHEET 2 OF 2 SCALE: 1:8

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	BW18505	MAINFRAME T30-27XX	1
2	XEB101000	5/8 LOCKWASHER	4
3	XAE081312	1/2-13 X 1 1/2 FLANGED HHCS	6
4	BW18530	BEARING BODY	2
5	BW21065	PIVOT BEARING SPACER	2
6	BW99320	SPHERICAL BEARING 1 1/4	2
7	XAE061608	3/8-16 X 1 FLANGED HHCS	8
8	BW01110	GREASE FITTING - 1/4-28 SHORT	2
9	BV00025	116 X 1/8 NPT ORIFICE PLUG	2
10	BV00064	6T X 6S ORIFICE FITTING	1
11	BR04842	6502-06-06 MJ-FJS 45 DEG	2
12	BR03830	6400-06-06 M TUBE 0-RING	1
13	BW07030	MOUNT PLATE H	1
14	BW07140	PLATE STUD	6
15	XDC082000	1/2-20 NYLOK NUT	6
16	BW18300	ACTUATOR	1
17	BW18503	BEARING MOUNT	2
18	XAB101110	5/8-11 X 1 1/4 SHCS	4





5/22/2020 DATE:

NOTED


MATERIAL:

UNLESS OTHERWISE SPECIFIED: T30-27 ACTUATOR DIMENSIONS ARE IN INCHES TOLERANCES: FRACTIONAL±1/32 ANGULAR: MACH±1° BEND ±1° TWO PLACE DECIMAL ±0.010
THREE PLACE DECIMAL ±0.005

MAINFRAME SUB ASSY H2-2739-41-43

REV DRAWING NO BWA18502 PARTS 00

SCALE: 1:10 WEIGHT: 147.601 # SHEET 1 OF 1





4/12/2022 DATE: MATERIAL: NOTED

UNLESS OTHERWISE SPECIFIED: BU186XX
DIMENSIONS ARE IN INCHES
TOLERANCES TOLERANCES: FRACTIONAL±1/32 ANGULAR: MACH±1° BEND ±1° TWO PLACE DECIMAL ±0.010 THREE PLACE DECIMAL ±0.005

SCALE: 1:8

DRAWING NO REV BWA18504 PARTS 00

WEIGHT: 139.432 # SHEET 1 OF 2

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	BW18506	MAINFRAME	1
20	XEB101000	1/2 LOCKWASHER	14
3	XDA082000	1/2-20 HEX NUT	14
4	BW07030	MOUNT PLATE H	1
5	BW07140	PLATE STUD	6
6	BW18503	BEARING MOUNT	2
7	XAE081312	1/2-13 X 1 1/2 FLANGED HHCS	6
8	BW18530	BEARING BODY	2
9	BW21065	PIVOT BEARING SPACER	2
10	BW99320	SPHERICAL BEARING 1 1/4	2
11	XAE061608	3/8-16 X 1 FLANGED HHCS	8
12	BV00025	116 X 1/8 NPT ORIFICE PLUG	2
13	BV00064	6T X 6S ORIFICE FITTING	1
14	BR04842	6502-06-06 MJ-FJS 45 DEG	2
15	BR03830	6400-06-06 M TUBE TO O-RING	1
16	BW07105	ACTUATOR MOUNT STUD	8
17	BW18013	27K ACTUATOR MT BRKT	4
18	BW18300	27K HELICAL ACTUATOR	1
19	XAB101110	5/8-11 X 1 1/4 SHCS	4
20	XEB101000	5/8 LOCK WASHER	4



4/12/2022 DATE: MATERIAL: NOTED


DO NOT SCALE DRAWING UNLESS OTHERWISE SPECIFIED: BU186XX
DIMENSIONS ARE IN INCHES
TOLERANCES. TOLERANCES: FRACTIONAL±1/32
ANGULAR: MACH±1° BEND ±1°
TWO PLACE DECIMAL ±0.010
THREE PLACE DECIMAL ±0.005

SCALE: 1:8
WEIGH

MAINFRAME SUB ASSY

REV DRAWING NO 00

WEIGHT: 139.432 # SHEET 2 OF 2



BARKER PRODUCTS 1310 MILLER ROAD GREENVILLE, SC 29607

DRAWN BY: R WYMAN

8/1/2017 DATE: MATERIAL: NOTED

UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN INCHES TOLERANCES: FRACTIONAL±1/32
ANGULAR: MACH±1° BEND ±1°
TWO PLACE DECIMAL ±0.010
THREE PLACE DECIMAL ±0.005

H2-25 LIFTS

SCALE: 1:4

DRAWING NO **REV** BWA18540 01

WEIGHT: 74.297 # SHEET 1 OF 2

ITEM NO.	PART NUMBER	DESCRIPTION	EXPLODED PARTS/QTY.
1	BW18530	BEARING BODY	4
2	BW99320	SPHERICAL BEARING 1 1/4	4
3	XAE061608	3/8-16 X 1 FLANGED HHCS	16
4	BW21065	PIVOT BEARING SPACER	4
5	BZ03451	SUPPORT PLATE	1
6	BW17130	HOOK BEARING MOUNT	4
7	BW03195	12-DU-12 BEARING	4
8	XAH061620	3/8-16 X 2 1/2 CARRIAGE BOLT	4
9	XDC061600	3/8-16 NYLOK NUT	4
10	BW01110	GREASE FITTING - 1/4-28 SHORT	4
11	BW00800	SADDLE	1
12	XAA061610	3/8-16 X 1 1/4 HHCS	3
13	XAA061618	3/8-16 X 2 1/4 HHCS	4
14	XEB061000	3/8 LOCKWASHER	3
15	XDA061600	3/8-16 HEX NUT	3
16	BWA07490	HOOK SUB ASSY	1
17	BW18540	LIFT PLATE	1

P	BARKER PRODUCTS 1310 MILLER ROAD GREENVILLE, SC 29607
---	--

DRAWN BY: R WYMAN

DATE: 8/1/2017

MATERIAL: NOTED

DO NOT SCALE DRAWING

UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN INCHES
TOLERANCES:
FRACTIONAL±1/32
ANGULAR: MACH±1°BEND±1°
TWO PLACE DECIMAL ±0.010
THREE PLACE DECIMAL ±0.005

SCALE: 1:6


LIFT PLATE SUB ASSY H2-25 LIFTS DRAWING NO BWA 18540

WEIGHT: 74.297 # SHEET 2 OF 2

REV

01

ITEM N	O. PART NUMBER	DESCRIPTION	EXPLODED PARTS/QTY.
1	BW18550	hook shaft	1
2	BW07560	WOODRUFF KEY #806	3
3	BW07490	HOOK	1
4	BW06780	HOOK DRIVE	2
5	XEB061000	3/8 LOCKWASHER	3
6	XAB061612	3/8-16 X 1 1/2 SHCS	3



BARKER PRODUCTS 1310 MILLER ROAD GREENVILLE, SC 29607
--

DATE: 8/1/2017
MATERIAL: NOTED

DO NOT SCALE
DRAWING
UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN INCHES
TOLERANCES:
FRACTIONAL±1/32
ANGULAR: MACH±1° BEND ±1°
TWO PLACE DECIMAL ±0.010
THREE PLACE DECIMAL ±0.005

HOOK SUB ASSY H2-25 DRAWING NO

BWA07490 00 005 SCALE: 1:4 WEIGHT: 6.177 # SHEET 1 OF 1

REV



BP LIFTS

By Barker Products
1310 Miller Road, Greenville, SC 29607
Phone:800-349-3149—Fax:864-297-1292



BPH27-186XX SERIES LIFT UNIT WARRANTY

Barker Products warranties each new dump unit to be free of defects in material and workmanship under normal use and service for a period of 1 year or 2000 hours of operation, whichever comes first, from the date of delivery.

This warranty excludes any obligations by BARKER PRODUCTS for the cost of down time. BARKER PRODUCTS will not warranty any dump unit which has been subject to misuse, neglect, alteration, or damaged by an accident.

On any work not performed by BARKER PRODUCTS or it's representitive, the customer will be responsible for freight charges on all parts shipped under warranty. Parts will be invoiced at time of shipment. Defective parts must be returned to BARKER PRODUCTS within 30 days. If the part is determined to be defective the customer will be credited for the original invoice.

Customer warranty labor charges must be approved by BARKER PRODUCTS in advance. If not contacted for approval, BARKER PRODUCTS will not be liable for the warranty labor charge.

Limit hydraulic input pressure to 2000PSI